



## 1.2TSI BOOST TAP FITTING KIT



1. Locate the map sensor which is attached to the inlet manifold (circled above). Undo both screws and lift to remove .
2. Insert the map sensor in to the Forge boost tap block ensuring the arrow on the block points towards the sensor. Place in position on the manifold with the cork gasket underneath. Fit with supplied screws or bolts depending on which type fits your engine.
3. The silicon hose can now be fitted to the pipe and routed to the required location.

Check out [WWW.FORGEMOTORSPORT.CO.UK](http://WWW.FORGEMOTORSPORT.CO.UK) and [WWW.FORGEMOTORSPORT.COM](http://WWW.FORGEMOTORSPORT.COM)

For a full range of performance products for your vehicle.

As always, with any questions or concerns about this product or anything else, please feel free to contact your local or preferred Forge Motorsport Dealer/ Installer, or you may contact us directly.

Forge Motorsport UK – (+44)1 452 380 999 / [info@forgemotorsport.co.uk](mailto:info@forgemotorsport.co.uk)

Forge Motorsport US – (407)-447-5363 / [sales@forgemotorsport.com](mailto:sales@forgemotorsport.com)



**ENGINEERED FOR PERFORMANCE**