



## 1.0 TSI Boost Tap Fitting Kit Installation Instructions



1. Locate the map sensor which is attached to the inlet manifold. Remove both screws (if present), hold back retaining tabs and lift map sensor out.
2. Insert the map sensor in to the Forge boost tap block.
3. Position cork gasket on manifold and place boost tap block on top. Fasten with the two shorter screws supplied, if the shorter screws do not feel secure then use the two longer screws supplied.
4. The silicone hose can now be fitted to the pipe and routed to the required location.

For a full range of performance products for your vehicle

Check out [www.forgemotorsport.co.uk](http://www.forgemotorsport.co.uk) and [www.forgemotorsport.com](http://www.forgemotorsport.com)

As always, with any questions or concerns about this product or anything else, please feel free to contact your local or preferred Forge Motorsport Dealer/Installer, or you may contact us directly.

Forge Motorsport UK – (+44)1 452 380 999 / [info@forgemotorsport.co.uk](mailto:info@forgemotorsport.co.uk)

Forge Motorsport US – (407)-447-5363 / [sales@forgemotorsport.com](mailto:sales@forgemotorsport.com)

